



INFINITE HUB INSTRUCTION HOW TO GROUP MOTORS

LunaTM TECHNOLOGY




STEP 1: ADD A NEW MOTOR

Tap the '+' button to add new motor




STEP 2: ACTIVATE PARING MODE

Press and hold the **PROG** button of the motor until it remains green to enter paring mode.




STEP 3: START PARING

Tap the '⋮' button and tap 'Start Pairing'. The motor will jog once for successful pairing.




STEP 4: PAIR OTHER MOTORS

To pair other motors to the same group, tap the '⋮' of the same line as the initial motor that was paired, and program the same way.




STEP 5: RENAME GROUP

To rename group press the 'Edit' button.




STEP 6: RENAME GROUP

Press '✎' on top right.



STEP 7: RENAME GROUP

Change the group name.



ALL DONE!

The group has been set for your motor.